

## Problems

## Possible Cause / Solution

6. MOH works but audio does not stop when call is picked up in 1 or 3 settings.
  - Wire distance to adapter is too long, Centralize the location of device to be as close as possible to all the phones. Try the 2 setting for maximum power.
  - If you are re-wiring "daisy chain" wiring works better than "star" or "home run" or Independent wiring
  - Press FLASH button to stop the music.
7. Some Phones work , some do not
  - All your phones need to be same model for activation in 1 or 2 settings. If you mix different phone models, Use the 3 setting (refer to pages 3 or 4 for more details)
8. Randomly Hold music starts to play by it self or does not activate in 1, 2 or 3 settings
  - The call needs to be on Hold min. 2 sec. before you may pick it up.
  - When you hang up, wait 2 seconds before selecting the same line again.
  - Check for extra devices sharing that line like Message indicator, Answering machine, Alarm system, Modem etc. Use a "privacy module" between the line and that extra device to keep them off the line when line is being used by your phone.
  - Set your Alarm system and/or your DSL line to share FAX line.
  - Excessive wiring- Total wire length per line must be under 500 feet ( Ex: if you have 9 wall jacks -no matter spare or a phone plugged in- each connected via a 100 foot wire to a common point then your total wire length is 9 x 100=900 feet )
  - Use FLASH button to deactivate music.
9. Audio shuts off or flickers
  - Extensive audio volume. Lower the volume to proper level.
10. Hold Music activates in a conference call or when two phones pick up at same time
  - If for any reason the hold music is activated inadvertently, it can always be deactivated by pressing the FLASH button in any setting.
  - Conference calls can be done a better way: Press FLASH, you will get a dial-tone now dial the phone number of the 2<sup>nd</sup> party then press FLASH to join the two calls together.



**Model # SX8600**



Rev 24E5

**All-In-One Auto Attendant + Greeting + Music-On-Hold Player/Recorder/Adapter**

- Plug the included AC adapter. (110V AC to 12V AC)
- Confirm that all 4 Red LED lights in front of this unit are double **BLINKING**
- Use one of your telephones and unplug the cord for L1/L2 from it and connect it to 1/2/3 PHONE LINES jack on SX8600 (the 1<sup>st</sup> jack from 12VAC), now connect 1/2/3 TELEPHONE jack on SX8600 (3<sup>rd</sup> jack) to your telephone using the provided phone cord, make sure you have dial tone on your lines 1 and 2
- Now unplug the cord for L3/L4 from your phone and connect it to 3/4 PHONE LINES jack on SX8600 (the 2nd jack from 12VAC) and connect 3/4 TELEPHONE jack on SX8600 (4<sup>th</sup> jack) to your telephone using the provided phone cord, make sure you have dial tone on your lines 3 and 4
- Observe that as you connect the lines the blinking lights turn OFF. (on non existing lines the lights keep blinking and that is OK)
- Alternatively you may use a splitter (T adapter) at the Wall jack to connect both this device and a telephone (in that case the 3<sup>rd</sup> and 4<sup>th</sup> jacks are not connected)
- Set the volume to mid level.
- Insert the Flash card into the blue connector in the front of unit, the Green status LED in the back of the unit will turn ON.



**Please note that just one telephone is optionally connected to this device, other telephones remain connected to their own wall jacks.**




**invotel**

Innovative Telecommunication Technology LLC.  
1112 Montana Ave Suite 250 Santa Monica, CA 90403 USA  
Toll-Free: 800-747-0708 Tel: 310-899-0078 Fax: 310-230-5346

**Connection Test:** To confirm that everything is connected correctly, select line 1 on the phone, confirm that L1 Red LED on SX8600 (left most LED) turns ON, then press the L1 Audio Test button to hear the audio. Double check your connections or adjust the volume if needed.

**Switch setting:** *Please Read the Operation instructions for each setting carefully*  
There are two 3 position switches on the SX8600 that control the operation of the device:



Regular 1 to 4 line telephones have differences when it comes to Music-On-Hold activation compatibility, some models work by just pressing HOLD button some work via Flash then Hold, this switch lets you find out which setting works best for your telephones.

**IMPORTANT NOTE:** The audio may activate in the middle of a call due to factors like excessive wiring (see page 12 item 8), bad or old wiring, existing unstable lines, sparks, too many wall jacks, Noisy phone lines, Bad telephones, "Hot Lines" (see P6 special cases) If that ever happens, press the **FLASH** button to stop the audio! and continue your conversation. The **FLASH** button is found on every telephone, it could be labeled as **CALL WAIT / FLASH** or **LINK** or **ON** or **TALK** button

**Audio Test on Line 1:** select L1 on your phone and press the **Audio Test** located next to power connection. Adjust the volume to mid level or check the FLASH card to hear the audio.

Note1: You can not perform audio test on lines 2, 3 or 4

Note2: Do not set the volume too loud it may flicker or shut off the on-hold audio.

Note3: **Do not use a Cell phone to setup or test the device.** Use a fax line, etc.

## Trouble Shooting:

Problems	Possible Cause / Solution
1. Adapter not working or stopped working	Unplug the 12VAC plug from the back of the Invotel adapter and unplug the phone lines; Wait 60 seconds then plug them back in, make sure the AC adapter is plugged in securely.
2. Adapter does not activate or stopped activating	telephone was changed or power failure - <u>do as above</u> , then select L1, L2, L3, L4 making sure that dial tone is there.
3. Red LED double blinks ON then turns OFF on some lines	Some phone Lines are removed from MOH adapter or do not exist. on non existing lines the lights keep blinking and that is OK) Un-plug phone lines for 5 seconds and plug it back in.
4. No Audio or Audio not Loud enough	Select the line 1 on the phone and push the Audio Test button located in the back of unit to hear the Audio, adjust the volume if needed to hear it. Check the flash card, Unplug -Plug back IN.
5. Audio Test is OK but no audio when Hold is pressed in <u>1</u> <u>2</u> or <u>3</u> settings.	<ul style="list-style-type: none"> <li>• If answering a call allow 1 second before pressing Hold.</li> <li>• You may need your "Local service" with the dominant phone company in your area (not 3<sup>rd</sup> party local service)</li> <li>• Is your location within city limits? are all your phone numbers DSL qualified? your location may need to be close enough to your phone company's central office to guarantee for Hold button activation. That is why some discount phone companies service does not work even though you have compatible phones for Hold activation.</li> <li>• Use the device in position 3 setting via Flash then Hold.</li> <li>• Some telephones need other settings (see page 6).</li> </ul>

**DSL:** If you have DSL line, this device needs to be installed after the DSL filter (otherwise internet may not work properly)

**VOIP/Vonage:** if you have D-Link VTA-VD phone adapter, you must use single line phone cords to connect it to SX8600

## Notes: Day/Night mode, Auto attendant and Greetings:

BANK  
Bank1 / Bank2 

Bank1 contains the "Holiday Format" and Bank2 contains the "Normal Format" hold music (normally switch is in Bank 2 unless you record your flash card differently). Use the bank switch any time to select between these two productions.

**Day Mode / Night Mode:** In switch positions A or B in which the device answers the lines, set to "Day Mode" during day and "Night Mode" during the night as follows:

- 1) Select any available line ( L1, L2, L3 or L4 ) to get a dial tone
- 2) Press FLASH you will get dial tone
- 3) Press FLASH you will get dial tone again
- 4) Press # you will get a prompt "device is set to Day mode" or Night Mode"
- 5) Hang up

**Day Greeting:** This message is heard when the device answers the lines in "Day Mode" it can be up to 30 seconds.

**Night Greeting:** This message is heard when the device answers the lines in "Night Mode" it can be up to 30 seconds.

**Transfer Message:** This message is heard just before the line is going to ring again, like "please hold while we transfer your call" it can be up to 4 seconds.

All greetings, messages and the Hold Music are stored on the same Flash card

### Examples of typical office use:

If you do not want any greeting stuff just set the switch to **C** and use the device just for Music-on-hold function. The other switch is in Bank2 for "Normal Format"

Example of a night greeting:

...our office is now closed... our normal office hours are...please stay on the line to leave a message... ; set your answering machine or voice mail service to answer at 2<sup>nd</sup> or 3<sup>rd</sup> ring or more so when the device rings the lines again it can take the message.

Example of a day greeting: "...Thank you for calling XYZ.....please hold for a representative..."

during the day to temporarily disable the auto attendant, flip the switch to **C**

## Music on hold activation:

activation in Positions 1 or 3 via just Hold

1 2 3



Start with position **1**, make or receive a real call, the LED on the SX8600 turns ON solid, then simply press the **(HOLD)** button on your telephone, the Music will be heard to the caller and the LED on the SX8600 will start to BLINK, to return to the call just re-select that line. (Be sure to allow 1 or 2 seconds before putting a call on HOLD). If it did not work hang up and then try it again 2 or 3 times.

**Position 3:** if after a few tries it is not working hang up and change the switch to position 3 and try it a few times.

**Deactivating hold music manually** If for any reason the hold music is activated inadvertently, it can be deactivated by pressing the **(FLASH)** button

The following are examples of phones that work in position **2** or **3** via Flash then Hold:

American Venture, ATT 962, ATT 972, Casio any model, Airway 2 line, Airway 4 line, Panasonic KX-TG 2000B, KX-TG4000B, KXTG2000, KX-TG2720, KX-TG2730, KX-TG2740, KXTG4000, KX-TGA200, KXTGA400, KX-TGA420, SBC 410,

### List of corded regular phones compatible via Hold Button activation:

Please note: This is a partial list, there are other factors relevant to activation via Hold button in these settings-see-the trouble shooting section or special setting. If your phone is not on this list try it any way or use the setting **2** or **3** that works on all phones via Flash then hold.

**AT&T:** 21070, 262, 272, 412, 422, 4952, 612, 622, 712, 722, 732, 742, 752, 812, 822, 830, 832, 842, 843, 853, 854, 874, 902, 912, 922, 944, 945, 952, 953, 954, 955, 964, 974\*, 984\*, 982, 992, SIGNATURE, FT483 (\* rev prior to 11/2006)

**Brother Quatro:** 412

**Bell:** 223, 232, 259, 261, 268, 367, 470, 52905, Sonacor 412, 412CID, 4900, BE5200, BE5300, Techline 420

**GE:** 187, 2-9315-A, 2-9318, 2-9435-A -B -C, 2-9436-A, 2-9438-A, 2-9450-A -B -C -D -E -F, 2-9439-A to -EGL, 2-9451A, 2-9481, 2-9487GE2-A, 2-9488, 2-9638-A, 2-9975, 2-9488GE2-A

**IBM:** 412, 412CID, 4900

**Northern Telecom:** Unity

**Phonemate:** PMG-4600

**Panasonic:** KX-T3110 3120 3122 3135 3145 3155 3160 3165 3170 3175 3280 3980-H 3980-R7 3981, KX-TC930, KX-TS20, KX-TS21, KX-TS25, KX-TS27, KX-TS208, VA-8400  
**Radio Shack:** 206, 208, 209, 210, 212, 411, 412, 612, 43-373D, 43-430, 43-642, ET-180, 43-470, ET-184, ET-192, ET-193, 43-622, 43-469, 1710, 1753

**RCA** 25403 RCA, 25413, 414, 415 RCA-2, all models including cordless portion.

**Sony:** IT-M804

**SBC:** 2105, 4000

**Southwestern Bell:** FT325, FT360, FT365BL FT383, FT412, FT483, FT484

**Sprint/Radio Shack:** SP-702 / 43-5702, SP-705

**TT Systems:** 4012, 412, 412CID, 4900, 4300, 5100, 5200, 5300, 7993

**Vtech:** 4121

## Music on hold activation:

### activation in Positions 2 or 3 via Flash then Hold

Hang up and set the switch to middle or right most position

1 2 3



To activate: press **FLASH** then **HOLD**

To deactivate just re-select that line and press **FLASH**

**Voice Deactivation:** if the call has been on Hold at least a few seconds, it can also be deactivated by just **speaking** over the Audio for example say : “Hi I am Back” .

If for some reason you are not able to voice -deactivate, try speaking a little louder and more direct into the microphone. Remember you can always use the Flash button to deactivate the audio as well.

**Want to use just one button ?** Press **FLASH** to activate MOH and when ready to go back to caller just speak over the audio!. Or press Flash again. Note: this does not hold the line so the other party may still hear you, set the volume louder to mask it.

In position **2** the device works only via Flash then Hold, in position **3** the device works via Flash then Hold or just Hold (if you have a compatible phone). This mode of operation is useful when you have mix of phones that some are compatible with Hold only activation and some activate via Flash then Hold.

Note that since Flash button is used in this case to activate the audio you need to use Flash -Flash for things like: **Call waiting , 3 way calling, Centrex Call Transfer**

**Example ( for positions 2 or 3 )** to answer a call waiting call press **FLASH FLASH**

**Example (position 2/ 3 )** to make a 3 way or conference call press **FLASH FLASH** you will get a dial-tone now dial the desired phone number & press **FLASH FLASH** to join the two calls together.

**NOTE:** If you have “**Call Waiting**” service, only one call may be placed on Music-On-Hold, the other call is held in the phone company central office in silence not in your office.

Tip: If you have audio flicker problem , Reduce the Volume

## Package Content:

SX8600 Digital Player/Recorder/adapter unit  
Power adapter 110v AC to 12v AC 600 ma  
3.5mm male to 3.5mm male audio cord 6'  
2 Rj-14 phone cords  
User's Manual  
MX9008 or MX9017 Flash Card  
Microphone/Headset

## Warranty

This product is warranted against defects for a period of Five (5) year from the date of original invoice. We will repair/replace the Product with no charge for parts or labor within this time. To obtain warranty service the Product needs to be returned freight prepaid by the customer with a copy of original invoice. This warranty does not apply if in the sole opinion of Innovative Telecommunication Technology LLC, the product has been tampered with or damaged by lightning or any other acts of nature, misuse, neglect or unauthorized service.

EXCEPT AS SPECIFICALLY PROVIDED IN THIS AGREEMENT, THERE ARE NO OTHER WARRANTIES, EXPRESSED OR OTHERWISE, INCLUDING, BUT NOT LIMITED TO ANY IMPLIED WARRANTIES OR MERCHANTABILITY OR FITNESS FOR A SPECIAL PURPOSE. IN NO EVENT SHALL INNOVATIVE TELECOMMUNICATION TECHNOLOGY LLC BE LIABLE FOR LOSS OF PROFITS OR BENEFITS, INDIRECT, SPECIAL, CONSEQUENTIAL OR OTHERWISE ARISING FROM ANY BREACH OF THIS WARRANTY OR OTHERWISE.

## Specifications:

**File Formats** supports any sound file format such as Windows .wav, MP3, WMA, etc.

**Frequency response** 20Hz to 20 KHz.

**Sampling rate** 8-bit/16-bit uncompressed PCM @ 8, 11, 12, 16, 22, 24, 32, 44 & 48 KHz

**Distortion** less than 0.1% THD

**Audio Quality** supports better than CD Quality at 188 KB/s

**Special effects:** supports Windows Media Files and SRS WOW Effects

**Memory Capacity** 1 to 34 minutes (17 minutes @ full 188 KB/s sample rate).

**Memory Type** Multi-level Flash, 100 years retention time at no power, 100K re-recordable

**Playback** auto-repeat

**Message loading** Email load, automatic via playing the email; CD load automatic

**Power supply** 110VAC 60 Hz. To 12VAC 600ma

**Audio output** 1000 mili watts, Mono RCA , 2V p-p @ 8Ω 4V p-p @ 600Ω, 8V p-p @ 1200Ω

**Size** 5.5" x 4" x 1.5" (L x W x H) **Color** Metallic Blue

**Weight** 1.50 pounds (2.00 pounds with power supply)

**Auto Attendant operations:** refer to page 1 for connections  
make sure switch is in **A** or **C** (not B)

### To hear the current greetings:

- set the bank switch to bank 1 for day greeting or bank 2 for night greeting
- **remove** the Microphone (usually RED color connector) from MIC IN jack
- **remove** the recording cord from the Audio IN jack
- **connect** the head set to Audio Out Jack (RCA) or make a call and place yourself on Hold, adjust the volume level if needed so you can hear the on hold stuff.
- Press and hold the REC button for about 5 seconds till the Green status light turns OFF, now release the REC button and you will hear the current greeting.

### To hear the current Transfer message:

- set the bank switch to bank 2, remove/make the connections as above.
- Press and hold the REC button for about 5 seconds till the Green status light turns OFF, Hold it pressed 5 more seconds till the Green turns back ON, now release the REC button and you will hear the current transfer message.

### To Record a new Greeting via Microphone: (not available in model SX8600E)

- set the bank switch to bank 1 for day greeting or bank 2 for night greeting
- **connect** the Microphone to MIC IN jack (usually RED color connector)  
you may optionally connect the recording cord to Audio IN jack (if you want to record a back ground music)
- **connect** the head set to Audio Out Jack (RCA) or make a call and place yourself on Hold, adjust the volume level if needed so you can hear the on hold stuff
- Press and hold the REC button for about 5 seconds till the Green status light turns OFF, now release the REC button and you will hear the current greeting.
- Press the REC button to start recording your new greeting and begin speaking into the microphone (you have up to 30 seconds), press REC again when you are finished, it will play it back again for you, you may Press REC again during the playback if you need to re-record, when you are done let it play the final recording for you and do not press REC and it will automatically exit to normal ON hold playback.

### To Record a new Transfer message via microphone: (not available in SX8600E)

- set the bank switch to bank 2, make the connections as above.
- Press and hold the REC button for about 5 seconds till the Green light turns OFF, Hold it pressed 5 more seconds, the Green turns ON, now release the REC and you will hear the current transfer message.
- Press the REC button to start recording your new transfer message and begin speaking into the microphone (you have up to 4 seconds), press REC again when you are finished, it will play it back again for you, you may Press REC again during the playback if you need to re-record, when you are done let it play the final recording for you and do not press REC and it will automatically exit to normal ON hold playback.

**To Record a new day or night greeting from an external audio source**  
(not available in model SX8600E)

- set the bank switch to bank 1 for day Greeting or Bank 2 for night greeting
- **remove** the Microphone from MIC IN jack
- **connect** the recording cord to Audio IN jack
- **connect** the head set to Audio Out Jack (RCA) or make a call and place yourself on Hold, adjust the volume level if needed so you can hear the on hold stuff
- Press and hold the REC button for about 5 seconds till the Green status light turns OFF, now release the REC button, Green and RED begin turning ON/OFF continuously to indicate it is ready and waiting for incoming audio, now play your audio from your PC etc. Recording starts automatically Solid RED, when audio finished you need to press REC button to stop it.

**To Record a new transfer message from an external audio source**  
(not available in model SX8600E)

- set the bank switch to bank 2
- **remove** the Microphone from MIC IN jack
- **connect** the recording cord to Audio IN jack
- **connect** the head set to Audio Out Jack (RCA) or make a call and place yourself on Hold, adjust the volume level if needed so you can hear the on hold stuff
- Press and hold the REC button for about 5 seconds till the Green status light turns OFF, hold it pressed 5 more seconds till Green turns back ON, now release the REC button, Green and RED begin turning ON/OFF continuously to indicate it is ready and waiting for incoming audio, now play your audio from your PC etc. Recording starts automatically Solid RED, when audio finished press REC button to

**Auto Attendant and greetings:**

You may pick up the line at any time during the playback of the greeting messages or the on hold for immediate connection to the caller. Once the line is picked up the auto attendant operation for that line ends. If you place the call on Hold the music on hold function continues to operate until the call is hung up.

In **B** setting the device answers the line on the 1<sup>st</sup> Ring then it plays the day greeting or night greeting (depending on day/night mode of operation), it then rings through on the same line until you pick up the ringing line or your answering device answers it.

In **A** setting the device answers the line on the 1<sup>st</sup> ring and plays the day / night greeting, if it is set to day mode it then rings the same line again to see if you want to take it or not, if you did not, it takes the caller to On hold automatically playing the on hold messages, at any time you may pick up the line to talk to the caller. (the call is kept on hold for up to 30 minutes). Every minute the device rings that line again to remind that you still have a call on Hold, it will also play a short transfer message each time it is about to ring the line, such as "Your call is Next" or "please stay on the line while we transfer your call" at the end if you still did not take the call it will ring it through that line continuously until the call is answered; you may place the call on Hold for Music On hold at any time thereafter.

If the device was in night mode, it just rings the same line continuously after the initial night greeting until your answering device or voice mail service takes a message.

The day or night greeting messages (each up to 30 seconds long- is a good way to provide the repeat information like office hours, web site address, etc.)  
see the programming section to change the # of rings or to play/record the greetings etc.

**Other settings:**

If audio activates suddenly in 3 switch settings, your lines may be "too powerful" Try 1 setting.

**MX9008 / MX9017 Flash Cards**

The MX9008 or MX9017 is a Flash card usually pre-recorded with the audio prior to your installation and it holds the audio all the time even if power is removed. When the power is restored the play back automatically resumes from the card. This device is designed for automatic player turn OFF once the flash card is removed, and automatic turn ON when the flash card is re-inserted. If you had any trouble remove the power by unplugging the AC adapter from the player, Install the new flash card, then re-apply the power.

*Unlike other Flash based cards that compress the audio, voice and audio signals are recorded directly into solid state memory in the MX9008 card in their natural, un-compressed form, providing superior quality voice and music*

**Message Duration:** There is a total of **7.5** minutes available for recordings of Bank1 and Bank2 with MX9008 card and **16** minutes with MX9017 card.

**BANK Selection:** There are 2 Banks in SX8600, BANK1 & BANK2 - one Bank holds the primary audio file, the other BANK holds the extra audio file(optional) such as "Holidays", special events, weekend special sales, promotions, etc. You can switch from Bank1 to Bank2 or vice versa any time via the BANK selection switch.

## Manual BANK2 Recording:

The SX8600 model has dual banks and a Bank1/Bank2 switch for immediate playback of bank1/bank2 by just flipping the bank switch, the total default recording time on the MX9008 is 7.5 minutes (16 minutes on the MX9017), you must 1<sup>st</sup> record bank1 before recording in bank2 so for example if your Bank1 recording is 3 minutes long then Bank2 can be used for a second production of up to 4.5 minutes duration.


**Flexible duration:** Bank2 addressing is not fixed, you can record any duration in BANK1 and any duration in BANK2 as long as the total is 7.5 minutes or less for MX9008 or 16 minutes or less for MX9017 Flash card.

Examples of recording for the extra bank are “Holidays”, special events, sale promotions, etc. The SX8600 automatically calculates the Bank2 start point when you finish recording BANK 1.

**You need to record BANK1 1<sup>st</sup> Before you can record BANK2**  
after you finish recording bank1, the SX8600 automatically calculates the bank2 starting point

### To record into Bank2:

set switch to BANK2



and do the same 4 steps as recording in BANK 1

The device automatically starts it's normal playback, and will play what you just recorded and will keep repeating. If you need to re-record just repeat the 4 steps. During the playback you may flip the switch to Bank1 or bank 2 any time and device will play back that bank repeatedly.

**Frequent production recording tip:** If you need to re-record the Bank1, then you need to re-record the Bank2, therefore we suggest to keep the production that is not changed frequently in bank1 like “holidays recording” and the main production in bank2, so you only need to re-record bank2 each time you update.

(please note some music titles are not royalty-free and you may want to use the royalty-free music titles to avoid annual licensing payments to ASCAP and BMI for playing those titles on-hold)

## Programming number of Rings and Ring through times:

Operations (for A setting)	Switch set to	Result
# of Rings to answer the call after playing the greetings	B1	1 Ring
	B2*	2 Ring*
	B3	4 Ring
# of Rings to answer the call at the periodic 1minute intervals	C1	1 Ring
	C2*	2 Ring*
	C3	4 Ring
# of Minutes to hold the call then ring through	A1*	2 minutes*
	A2	8 minutes
	A3	30 minutes

\*denotes factory preset values

You can program each line on your phone for the number of rings or the duration independently, you may do this from any phone even if it is not connected to the SX8600

### To program:

- Set the switches for the desired operation above
- select L1 on your phone to get a dial tone
- wait about 10 seconds to hear the Hold music then press the Flash button, you will get confirmation via Hold music turning ON and OFF twice
- Hang up and repeat for lines L2...L4

Be sure to change the switches back to the way they were prior to programming.

**Example:** to change the number of rings to answer the call after playing the greetings from the factory preset value of 2 rings to 4 rings do as follows: set the switches to B3, select L1(dial tone), wait 10 seconds into dial tone and you hear the Hold music for a second now press Flash, you will get Hold music ON and OFF twice to confirm the operation was done. Do this for L2...L4 if you need changes to apply for those lines as well.

**Note: your changes remains intact even if power is lost or you remove the SX8600 entirely.**

To restore the factory settings you need to re-program the device to factory settings above.


Also note that the # of rings to answer the call before playing the greetings is fixed at 1<sup>st</sup> ring.

**Automatic Email Recording:** (This feature is available on SX8600E only)  
 SX8600E is the 1<sup>st</sup> device in the world with an exclusive feature: *"It can be automatically recorded by playing an email"*. The production audio emailed to you from your dealer contains a "coded noise file" that automatically activates & then stops the recording process (The RED Status LED light indicates recording is in progress, the noise codes themselves will not be recorded), all other audio that you play on your PC will not effect the SX8600E.

### Volume setting for recordings

The recording volume is directly effected by the volume setting on your PC, we recommend you set the media player volume to about 50% level, volume control & wave to 100% . as follows:

Double click on speaker symbol (located on lower right hand side of your screen) then adjust the Volume control and Wave to Maximum 100%



**Note on PC audio connection:** You may use male to female extension audio cords or other methods if you need to extend the length of the connecting cord (Maximum audio cord length 500 feet)

### Automatic CD recording (CD Auto Load):

(This feature is available on SX8600E only)

SX8600E can automatically be recorded from a PC CD ROM drive or a CD player, Just insert the CD you received from your dealer into the CD ROM drive of your PC or insert it into your CD player (volume mid level ), press the play button on the CD player and walk away. The CD contains a code that starts the recorder in SX8600E (RED Status LED turns ON) and then stops the recorder, the LED Green Status turns back ON and play back resumes. The CD player stops on its own.

### Adjusting Output VOLUME


If the On Hold audio volume is too low turn the VOLUME control clockwise; If it is too loud turn the VOLUME control counter clockwise to desired level.

### Live audio from Radio etc.. input/output RCA jack ( 8Ω )

If the Flash card is inserted, the big RCA jack can be used to connect the head set to monitor the audio content. (to connect a speaker to this RCA jack be sure to use a 5 inch or smaller speaker to avoid overloading the out put beyond it's limits). If the Flash card is removed, the built in digital player turns OFF and this RCA jack can be used as "input" for connection to an any Live audio source for the adapter function.

### Manual Recording: Connecting to an external audio source:

(not available in model SX8600E)



Connect the Audio IN jack to your audio source speaker or headphone jack using the provided 3.5mm to 3.5 mm audio cord. Select the bank you want to record

Refer to page P8 to adjust your volume levels

1. Press REC to stop the playback, GREEN/ RED STATUS LEDs Blink ON/OFF continuously.
2. Start your music/audio, email MP3 file etc. Recording starts **automatically** (or you may press REC to start recording manually if you prefer)
3. RED STATUS LED light turns ON solid to indicate recording in progress.
4. Recording stops automatically after 15 seconds of silence in the end of recording, the unit then removes the silences and resumes playback operation. (You may also press REC to stop recording if you prefer to control it manually). RED Status light turns OFF and Green Status will turn ON.

This **Automatic Start / Stop:** Feature on SX8600 allows you to **just start the audio and walk away, no need to watch the unit for end of recording.**

The device automatically starts it's normal playback, and will play what you just recorded repeatedly. If you need to re-record repeat the above steps.